

# User's Manual

## TX1001 Digital Thermometer

Thank you for purchasing this instrument.

For proper use, please read through this instruction manual prior to operation.



Yokogawa Meters & Instruments Corporation

IM TX10-01E  
4th Edition : Nov. 2006(KP)

### 1. Cautionary Notes for Safe Use of the Product

The following safety symbols are used on this instrument and instruction manual to ensure safe use.

- WARNING:** This symbol found on the back of the instrument, calls attention to a potential danger or hazard capable of resulting in a serious injury or loss of life, and the operator must refer to this instruction manual to avoid the danger or hazard.
- WARNING:** This symbol in this manual indicates a potential danger or hazard capable of resulting in a serious injury or loss of life.
- CAUTION:** This symbol in this manual indicates a potential danger or hazard capable of resulting in severe but not irreversible injury or damage. In some instances, the hazards may be those associated with WARNING symbols but are of significantly less magnitude.
- NOTE:** This symbol draws attention to information that is essential for understanding how to operate the instrument and/or instrument features.
- TIP:** Gives information that complements the present topic.

To avoid accidents, such as an electrical shock, which may lead to injury or the loss of life to the operator, or damage to the equipment, be sure to observe the following precautions.



- Do not use the instrument to measure where there is the risk of electrical shock.
- When handling a needle-type probe, be careful not to point the tip in the direction of any person as doing so may result in an injury.
- After measuring anything with a high temperature, do not touch the metal part of the measuring probe as this may result in a burn.




- When the instrument is stored for a long period of time, be sure to remove the batteries. Not doing so may result in a failure or malfunctioning of the instrument due to a leakage in battery liquid.
- Do not use deteriorated or damaged probes, as doing so will effect the precision of measurements.
- Before you detach the probe from the instrument, always remove the probe from the object being measured.
- When using a needle-type probe, do not insert the metal part of the measuring probe more than half its length into the object to be measured, as doing so may result in a burn or damage to the probe due to the handle of the probe heating up.
- Keep the handle of the probe and the cable that connects the probe to the instrument within a temperature range of -20°C to 50°C, as they are less resistant to heat than the metal part of the measuring probe.

#### Regarding Disassembling and Modification

Do not disassemble or modify the instrument in any way. The instrument should only be disassembled by a service engineer of Yokogawa.

### 2. Functional Description



Key	Operation and description	Display
<b>Power on</b> <b>POWER</b> SET	<ul style="list-style-type: none"> <li>Press this key to turn on the power.</li> <li>The auto power-off function turns off the power automatically about 10 minutes after the last key operation of any key other than the <b>POWER</b> SET key.</li> <li>To disable the auto power-off function, turn off the power, if the power is already turned on. Then simultaneously press the <b>POWER</b> SET key and <b>DATA HOLD</b> key. With this function disabled, the instrument will stay powered continuously.</li> </ul>	After the power has been turned on, all the elements of the display light up.
<b>Power off</b> <b>POWER</b> SET	<ul style="list-style-type: none"> <li>To turn off the power, press this key for 1 second or longer.</li> </ul>	<b>AUTO OFF</b>
<b>Select thermocouple type</b> <b>TC TYPE</b> + <b>POWER</b> SET ↓ <b>TC TYPE</b> ↓ <b>POWER</b> SET	<ul style="list-style-type: none"> <li>To select a thermocouple type from K, J, E, and T: If the power is already turned on, turn it off.</li> <li>Press and hold down the <b>TC TYPE</b> key while pressing the <b>POWER</b> SET key to turn on the power. The thermocouple type and unit on the display flash, indicating that the instrument is ready for changing thermocouple type.</li> <li>Every time the <b>TC TYPE</b> key is pressed the thermocouple type.</li> <li>Press the <b>POWER</b> SET key to accept the setting. <b>TIP:</b> The factory-set default is type K.</li> </ul>	K, J, E, T
<b>Hold</b> <b>DATA HOLD</b> <b>Release hold</b> <b>DATA HOLD</b>	<ul style="list-style-type: none"> <li>Use this key to hold the measured value on LCD.</li> <li>To hold, press this key.</li> <li>To cancel holding, press this key again.</li> </ul>	<b>HOLD</b>
<b>Burnout</b> —	<ul style="list-style-type: none"> <li>When the probe is not connected to the input connector (or the sensor opens), a burnout mark is displayed.</li> <li>For the 2-channel mode, the burnout mark is displayed when the probe is not connected to the selected channel (channel A and B, or channel A-B)</li> </ul>	

### 3. Measurement

This instrument can connect any of the 4 types of thermocouples: Type K, J, E, or T (it is set to Type K at shipment from the factory). Use an omega-type connector corresponding to the TC type for the probe.

- (1) Load the batteries (see section 5, Battery Replacement).**
- (2) Press the **POWER** SET key to turn on the power.**  
When the power has been turned on, all indications on the display light up for about 2 seconds, then a measured value appears.
- (3) Check the thermocouple type.**  
If you wish to change the current setting, turn off the power and follow the instructions in the section Select thermocouple type on the previous page.
- (4) Connect the probe to the input connector.**
- (5) When you have finished measurement, turn off the power by pressing the **POWER** SET key.**
  - The power may be turned off by the auto power-off function during measurement. In this case, press the **POWER** SET key to restart the instrument and continue measurement.



Yokogawa Meters & Instruments Corporation

Yokogawa Meters & Instruments Corporation

**International Sales Dept.**  
Tachihara Bld. No.2, 6-1-3, Sakaecho, Tachikawa-shi, Tokyo 190-8586 Japan  
Phone: 81-42-534-1413, Facsimile: 81-42-534-1426

**YOKOGAWA CORPORATION OF AMERICA (U.S.A.)**  
Phone: 1-770-253-7000 Facsimile: 1-770-251-2088

**YOKOGAWA EUROPE B. V. (THE NETHERLANDS)**  
Phone: 31-334-64-1611 Facsimile: 31-334-64-1610

**YOKOGAWA ENGINEERING ASIA PTE. LTD. (SINGAPORE)**  
Phone: 65-6241-9933 Facsimile: 65-6241-2606

**YOKOGAWA AMERICA DO SUL S. A. (BRAZIL)**  
Phone: 55-11-5681-2400 Facsimile: 55-11-5681-1274

**YOKOGAWA MEASURING INSTRUMENTS KOREA CORPORATION (KOREA)**  
Phone: 82-2-551-0660 to -0664 Facsimile: 82-2-551-0665

**YOKOGAWA AUSTRALIA PTY. LTD. (AUSTRALIA)**  
Phone: 61-2-9805-0699 Facsimile: 61-2-9888-1844

**YOKOGAWA INDIA LTD. (INDIA)**  
Phone: 91-80-4158-6000 Facsimile: 91-80-2852-1441

**YOKOGAWA SHANGHAI TRADING CO., LTD. (CHINA)**  
Phone: 86-21-6880-8107 Facsimile: 86-21-6880-4987

**YOKOGAWA MIDDLE EAST E. C. (BAHRAIN)**  
Phone: 973-358100 Facsimile: 973-336100

**LTD. YOKOGAWA ELECTRIC (RUSSIAN FEDERATION)**  
Phone: 7-095-737-7868 Facsimile: 7-095-737-7869

IM3E-2006.2

### 4. Precautionary Notes



- Each probe has its own maximum and minimum operating temperatures, so ensure that its temperature does not fall outside the specified range.
- As the probe is susceptible to corrosion, do not use the instrument for the measurement of gas or liquid, and refrain from measuring semi-solid particles and semi-viscous substances. After measurement, wipe the probe with a dry cloth.
- Do not apply a strong force to the upper and lower parts of the probe as doing so may result in the bending of the probe connector.
- When using the instrument be careful not to bend, drop, or strike the measurement probe.
- When measuring surface temperature using a surface-type probe, position the probe perpendicular to the surface of the object. Also note that the application of oil to the probe for the means of providing better contact can improve measurement accuracy.
- When measuring non-metallic surface temperature, make sure the measurement time is long enough to compensate for poor thermal conductivity.
- To ensure stable measurement, the instrument should not be subjected to a sudden temperature change.
- This instrument, with the exception of the connector section, is water-resistant but not waterproof. Therefore the instrument should not be immersed in water. If it is mistakenly immersed in water, remove it immediately and check to ensure that no water has penetrated inside the case. Although this instrument is designed so that any water penetrating into the connector does not permeate into the circuit inside the case, try to prevent any water entering the connector. If water does enter the connector, the burnout display may be unavailable.

### 5. Battery Replacement

When the batteries approach the end of their lives, the mark appears on the display. If this mark is displayed, replace the batteries. To replace the batteries:

- (1) Remove the battery box cover from the back of the instrument. Then replace the two AA alkaline dry batteries (LR6).**
- (2) Refit the cover to the battery box.**



- When inserting batteries, be careful not to mistake the polarity as this can damage the instrument.
- When the instrument is to be stored for a long period of time, remove the batteries.
- Do not leave dead batteries in the instrument as doing so may result in a failure or malfunction of the instrument due to a leakage in battery liquid.
- Both batteries should be replaced with new ones at the same time as replacing only one of the batteries may result in the charge leaking from the new battery to the old.

### 6. Cleaning and Maintenance Service

- If the instrument becomes dirty, wipe the instrument with a cloth that has been dampened with water and well wrung.
- If the instrument is very dirty, use a cloth that has been dampened with a diluted neutral detergent. Do not use other detergents, solvents, or chemicals. Doing so may cause a failure of the instrument.
- Avoid any water or other liquids from splashing onto the connector, as this may cause a failure of the instrument.
- For maintenance or repairs, contact Yokogawa Engineering Service (see the first page).

### 7. Specifications

Thermocouple type	K, J, E, T
Measuring range	Type K: -200°C to 1372°C Type J: -200°C to 1000°C Type E: -200°C to 700°C Type T: -200°C to 400°C
Measurement resolution	-200.0°C to 199.9°C: 0.1°C 200°C or higher: 1°C
Accuracy (instrument)	-200.0°C to -100.1°C: 0.1% of rdg + 1.0°C -100.0°C to 199.9°C: 0.1% of rdg + 0.7°C 200.0°C or higher: 0.2% of rdg + 1°C } (when the temperature at input jacks are stabilized)
Temperature coefficient	±(0.015% of rdg + 0.06°C)/°C
Measurement cycle	Approx. 1 second
Operating environment	0 to 50°C, 20 to 80% RH (no condensation)
Storage environment	-10 to 60°C, 5 to 95% RH (no condensation)
Power requirements	Two AA alkaline dry batteries (LR6)
Battery life	Approx. 450 hours
Display	Reflective LCD: 7-segment, 4-digit display and 30 character segments
Battery alarm	Displayed on LCD
Key operation sound	Internal buzzer sounds during key operation
Auto power-off	Turns off the power 10 minutes after the last key operation (can be disabled)
Degree of protection provided by enclosures	Equivalent to IP54 (when using the waterproof cover)
External dimensions	Approx. 151(H) × 56(W) × 33(D) mm (excluding protrusions)
Weight	Approx. 180 g (including batteries)
EMC standards	EMI (interference signal): EN55011, EN61326-1 (Class B, Group 1) EMS (immunity): EN50082-1, EN61326-1
Emission immunity	The accuracy ratings of all ranges are the sum of the accuracy levels in standard applications and the accuracy tolerances shown below, where the overall length of cable, including the probe, is assumed to be shorter than 3 m. Accuracy tolerance of all available ranges: ±5% of span (Tested at 3 V/m and for standard applications)

#### Accessories

Instruction manual, Two AA alkaline dry batteries (LR6)

### 8. Accessories (Options)

Temperature probes (for thermocouple type K)

Model	Probe type	Measuring range	Accuracy	Response time (second)	Sensor Diameter/Length (m/m)	Cord length
90020	rounded end	-50 to 600 °C	0.4% or ± 1.5°C	1.4	ø3.2 / 200	1.2 m
90021	rounded end	-50 to 600 °C	0.4% or ± 1.5°C	0.4	ø1.6 / 150	1.2 m
90022	rounded end	-50 to 600 °C	0.4% or ± 1.5°C	1.4	ø3.2 / 500	1.2 m
90023	needle	-50 to 500 °C	0.4% or ± 1.5°C	0.4	ø1.6 / 100	1.2 m
90024	needle	-50 to 500 °C	0.4% or ± 1.5°C	1	ø2.1 / 100	1.2 m
90030	Surface straight	-20 to 250 °C	0.75% or ± 2.5°C	2	ø15 (temp. sensing portion)	1.2 m
90031	Surface angled	-20 to 250 °C	0.75% or ± 2.5°C	2	ø15 (temp. sensing portion)	1.2 m
90032	Surface straight	-20 to 500 °C	0.75% or ± 2.5°C	2	ø15 (temp. sensing portion)	1.2 m
90033	Surface angled	-20 to 500 °C	0.75% or ± 2.5°C	2	ø15 (temp. sensing portion)	1.2 m
245907	Bead TC	-40 to 260 °C	0.75% or ± 2.5°C		1200 (including cord)	1.2 m

(90% response)

245921 Extension cable (5 m), 245922 Extension cable (10 m), 93011 Waterproof cover (5 pcs), 93012 Carrying case

### 9. Regarding This Manual

- The contents of this manual are subject to change without prior notice.
- This manual is intended to describe the functions of this product, not to guarantee that the functions are suited to the particular purpose of the user.